

New Methodology for Computing Thickness of Flexible Overlays of Military Airfield Flexible Pavements

2014 FAA Worldwide Airport Technology Transfer Conference
Galloway, NJ
August 5, 2014

Carlos Gonzalez , PE
US Army Engineer Research and Development Center
Vicksburg, MS

Dr. Alessandra Bianchini, PE
Air Force Civil Engineer Center
Tyndall AFB, FL

ERDC

Engineer Research and
Development Center



US Army Corps of Engineers
BUILDING STRONG®



Flexible Pavement Overlay

- Pavement overlay
 - ▶ Primary technique utilized in pavement maintenance
 - ▶ Increases the structural support of the pavements (design traffic growth or mission change)
- Design of pavement overlays
 - ▶ UFC 03-260-02 *Pavement Design For Airfields*
 - ▶ Based on empirical formulation
- Flexible overlay thickness based on
 - ▶ Thicknesses of the existing asphalt, base, and subbase layers
 - ▶ Required minimum thickness for the asphalt layer



Purpose of the Study

- Improve methodology for computing the flexible overlay thickness considering the structural condition of the existing asphalt layer
- Standardize the design and evaluation of flexible pavements overlaid with asphalt layers and account for existing structural conditions
- Help overall optimization of maintenance funding allocation limiting pavement overdesign



Flexible Overlay over Flexible Pavement Design Manual UFC 3-260-02

$$T_p = t_m + (t_o + t_e - t_m)E_f + t_b + t_{sb} \quad (1)$$

T_p – total thickness required above the subgrade

t_m – minimum thickness of asphalt


t_o – thickness of overlay

t_e – thickness of existing asphalt

E_f – equivalency factor for converting asphalt to an equivalent thickness of subbase

t_b – thickness of existing base

t_{sb} – thickness of existing subbase



BUILDING STRONG®

ERDC

Innovative solutions for a safer, better world

Flexible Overlay Equation

$$T_p = t_m + (t_o + t_e - t_m)E_f + t_b + t_{sb} \quad (1\text{bis})$$

Solving Equation 1 for t_o :

$$t_o = \frac{T_p - (t_m + t_b + t_{sb})}{E_f} + (t_m - t_e) \quad (2)$$




BUILDING STRONG®

ERDC

Innovative solutions for a safer, better world

Equation 1 Explained: Case 1, $t_m > t_e$




BUILDING STRONG®



Innovative solutions for a safer, better world

Equation 1 Explained: Case 2, $t_m \leq t_e$



BUILDING STRONG®

ERDC

Innovative solutions for a safer, better world

Limitations of the Current Methodology

- Does not take into account the quality or the structural condition of the existing asphalt layers
- Considers the asphalt layer to have full strength support and no deterioration



BUILDING STRONG®



Innovative solutions for a safer, better world

Approach

- Computation of the flexible overlay thickness through the introduction of an asphalt reduction factor
- Asphalt reduction factor
 - ▶ Quantifies the amount of the existing asphalt layer thickness that can still offer structural support
 - ▶ Can be based on distresses affecting the asphalt surface
 - ▶ Selected distresses commonly monitored during pavement evaluations



Flexible Pavement Overlay

$$t_o = \frac{T_p - (t_m + t_b + t_{sb})}{E_f} + (t_m - t_e) \quad (2 \text{ bis})$$

Extending Equation 2 to multiple bases, subbases, and introducing the asphalt reduction factor, Equation 3 is obtained:

$$t_o = \frac{T_p - [t_m + (\sum t_b + (1 - f_{ac})t_e) + \sum t_{sb}]}{E_f} + (t_m - f_{ac}t_e) \quad (3)$$

Where: $0.0 \leq f_{ac} \leq 1.0$



BUILDING STRONG®

ERDC

Innovative solutions for a safer, better world

Asphalt Reduction Factor, f_{ac}

If $f_{ac} = 1.0$

- Existing AC layer is in good condition, monolithic structure,
- full AC thickness contributes to the AC overlay

If $f_{ac} = 0.0$

- Existing AC layer is in poor condition,
- No thickness can contribute to the overlay,
- All asphalt layer thickness is considered a base and is added to the existing base



BUILDING STRONG®



Innovative solutions for a safer, better world

Built-in Assumptions

- When using f_{ac} , AC is converted to base with CBR=100 for values less than 1.0
- An existing base must have CBR>80 to be called a base; otherwise, it should be treated as a subbase layer




BUILDING STRONG®




Innovative solutions for a safer, better world

Example Assuming $f_{ac} = 1.0$



$$t_o = \frac{36'' - [4'' + (6'' + (1 - 1)3'') + 12'']}{2.3} + (4'' - 3'') = 6.09'' + 1'' = 7.09'' \text{ AC}$$

Example Assuming $f_{ac} = 0.0$



$$t_o = \frac{36" - [4" + (6" + (1 - 0)3") + 12"]}{2.3} + (4") = 4.78" + 4" = 8.78" \text{ AC}$$

AC Layer Condition Analysis

AC layer in poor condition, $f_{ac_c} = 0$

AC layer in good condition, $f_{ac} = 1$

$$t_{o0} - t_{o1} = \frac{T_p - [t_m + (\sum t_b + t_e) + \sum t_{sb}]}{E_f} + t_m - \frac{T_p - [t_m + \sum t_b + \sum t_{sb}]}{E_f} - (t_m - t_e)$$

With equivalency factor, $E_f = 2.3$ (asphalt concrete to subbase):

$$t_{o0} - t_{o1} = t_e \left(1 - \frac{1}{E_f} \right) = t_e \left(1 - \frac{1}{2.3} \right) = 0.565t_e$$

With respect to the existing AC thickness, an AC layer in poor condition requires about 60% more in thickness than an AC in good condition



BUILDING STRONG®

ERDC

Innovative solutions for a safer, better world

Examples

Pavement Layers	Example 1 Thickness, inches	Example 2 Thickness, inches
AC existing (t_e)	3	5
Base existing (t_b)	6	6
Subbase existing (t_{sb})	12	12
AC minimum thickness (t_m)	4	4
Total thickness needed (T_p)	35	35

	Overlay, inches											
f_{ac}	0	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	t_o, t_1
Example 1	8.35	8.18	8.01	7.84	7.67	7.50	7.33	7.16	6.99	6.82	6.65	1.70
Example 2	7.48	7.20	6.91	6.63	6.35	6.07	5.78	5.50	5.22	4.93	4.65	2.83



BUILDING STRONG®

ERDC

Innovative solutions for a safer, better world

Determination of the Asphalt Reduction Factor, f_{ac} for values between 0.0 and 1.0

- The asphalt layer is weakened in the presence of the Selected Distresses (cracking distresses) → distress relative area with respect to the other existing distresses
- The asphalt reduction factor is a function of the RATIO between the area of Selected Distresses and the total area of distresses


$$f_{ac} = \text{function} \left(\frac{\text{Relative area of selected distresses}}{\text{Total area of distresses}} \right)$$



Selected Distresses

Based on distresses diminishing the integrity of the asphalt layer

- Alligator cracking
 - @10% of distress density → Deduct Value (DV) is 43(L), 56(M), and 71(H)
- Block cracking
 - @10% of distress density → DV is 17(L), 24(M), and 42(H)
- Joint reflection
 - @10% of distress density → DV is 16(L), 38(M), and 55(H)
- Long./Transv. cracking
 - @10% of distress density → DV is 24(L), 36(M), and 54(H)




BUILDING STRONG®

ERDC

Innovative solutions for a safer, better world

Selected Distresses

- Alligator cracking
 - Block cracking
 - Joint reflection
 - Longitudinal and Transverse cracking
- For each distress, DV rapidly increases with the first 10% of Distress Density (DD) increase → PCI rapidly decreases
 - DD increase 0-10%, the DV increase average rate 3.38
 - DD increase 10-20%, 20-30%, DV increase average rate 0.7355




BUILDING STRONG



safer, better world

Asphalt Reduction Factor f_{AC}



$$f_{ac} = -3.38(A_{ratio}) + 1 \quad \text{for } A_{ratio} \leq 0.1$$

$$f_{ac} = -0.7355(A_{ratio}) + 0.7355 \quad \text{for } A_{ratio} > 0.1$$

$$A_{ratio} = \frac{\text{Selected Distress Area}}{\text{Total Distress Area}}$$



BUILDING STRONG®

ERDC

Innovative solutions for a safer, better world

Conclusions

- An asphalt reduction factor, f_{ac} , was defined as a function of the distresses affecting the existing asphalt surface and their severity and extent
- The distresses included those that clearly undermine the soundness of the asphalt layer and included cracking type distresses:
 - ▶ alligator cracking, block cracking, joint reflection cracking, and longitudinal and transverse cracking
- According to the procedure outlined, an asphalt layer in poor condition would require about 60% more in thickness than an asphalt layer in good condition



Questions?



BUILDING STRONG®

ERDC

Innovative solutions for a safer, better world